EXTERIOR BOX

NOTE: THIS DIMENSION IS THE LENGTH OF THE BASE PLATE + THE THICKNESS OF MATERIAL. WE ARE USING 18MM MATERIAL THICKNESS, SO WE NEED TO ADD 36MM TO THE LENGTH

NOTE:
THE LENGTH OF THE THIS IS THE SAME
AS THE WIDTH OF THE BASE PLATE.
IF YOU CHANGE THE BASE PLATE,
THEN CHANGE THIS DIMENSION

-83.6cm-

-60cm-

NOTE: THIS DIMENSION IS THE LENGTH OF THE BASE PLATE + THE THICKNESS OF MATERIAL. WE ARE USING 18MM MATERIAL THICKNESS, SO WE NEED TO ADD 36MM TO THE LENGTH NOTE: THE LENGTH OF THE THIS IS THE SAME AS THE WIDTH OF THE BASE PLATE. IF YOU CHANGE THE BASE PLATE, THEN CHANGE THIS DIMENSION

-83.6cm-

-60cm-

INTERIOR BOX

NOTE:
THE LENGTH OF THE THIS IS THE SAME
AS THE LENGTH OF THE BASE PLATE.
IF YOU CHANGE THE BASE PLATE,
THEN CHANGE THIS DIMENSION

_____56.4cm-

-80cm

· ·

NOTE:
THE LENGTH OF THE THIS IS THE SAME
AS THE LENGTH OF THE BASE PLATE.
IF YOU CHANGE THE BASE PLATE,
THEN CHANGE THIS DIMENSION

NOTE:
DIMENSION IS THE WIDTH OF THE
BASE PLATE - THE THICKNESS OF MATERIAL.
WE ARE USING 18MM MATERIAL THICKNESS,
SO WE HAVE TO REMOVE 36MM FROM THE LENGTH

DIMENSION IS THE WIDTH OF THE BASE PLATE - THE THICKNESS OF MATERIAL.


WE ARE USING 18MM MATERIAL THICKNESS,

SO WE HAVE TO REMOVE 36MM FROM THE LENGTH

-80cm-

-56.4cm-

BASE PLATE



GLASS PLATE

